


SYSTEM 9



CVM wireless volume master

User manual • Bruksanvisning • Manuel d'utilisation • Bedienungsanleitung • Manual del propietario

.....

SPECIFICATIONS

Type: WiFi volume control unit

Channels: 3

ID codes: 10

Dimensions:

Height: 150 mm

Width: 135 mm

Depth: 45 mm

WIRELESS FEATURES

Wireless full CD audio quality

No interference or delays

RF band (WIFI): 2.4 GHz

Sample rate: 48 KHz

Plug n' play, no software needed

Dedicated proprietary network protocol

Works with Mac/PC

Range: 20–100 m depending on conditions

Channel sniffing and frequency hopping

3 channels with 10 ID codes on each channel

SONAB[®]
Sound & Society

© Sonab Audio AB Sverige
Sonab[®], Sonab logotypen, är registrerade varumärken av Sonab Audio AB, Sverige. System 9TM. Alla rättigheter reserverade.
Sonab följer en policy om ständig produktutveckling. Specifikationer kan ändras utan föregående meddelande.

© Sonab Audio AB Sweden
Sonab[®], the Sonab logotype are all registered trademarks of Sonab Audio AB, Sweden. System 9TM. All rights reserved.
Sonab follows a policy of continuous advancement in development. Specifications may be changed without notice.

ENGLISH

WIRELESS TRANSMITTER SONAB CVM

FCC ID: XCO-SNBCVM
IC: 7756A-SNBCVM

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To satisfy FCC RF exposure requirements, a separation distance of 20 cm or more should be maintained between this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended. The antenna used for this transmitter must not be co-located in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pour satisfaire aux exigences de la FCC d'exposition aux radiofréquences, une distance de séparation de 20 cm ou plus doit être maintenue entre cet appareil et des personnes lors de fonctionnement du dispositif. Pour assurer la conformité des opérations au plus près que cette distance n'est pas recommandée. L'antenne utilisée pour ce transmetteur ne doit pas être co-localisés en conjonction avec toute autre antenne ou transmetteur.

Cet appareil est conforme à la Partie 15 des règlements de la FCC. L'opération est soumise aux deux conditions suivantes: (1) cet appareil ne peut causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent provoquer un fonctionnement indésirable.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

INSTALLATION

- 1. Place CVM within range of the CTX transmitter.**
 - 2. Place CVM as high as possible, preferably hanged on wall.**
 - 3. Place CVM freely and visible, not in closed compartments.**
- Avoid placing near or with blocking metal materials around of CVM unit.**

WHEN INSTALLING, ALWAYS OBSERVE THE NATIONAL INSTALLATION AND ACCIDENT PREVENTION REGULATIONS.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING:
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

CAUTION:
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

.....

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer’s instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Unplug this apparatus during lightning storms or when unused for long periods of time.
12. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

13. Damage Requiring Service

Unplug the apparatus from the wall outlet and refer servicing to qualified service personnel under three following conditions:

- A. When the power-supply cord or plug is damaged,
- B. If liquid has been spilled, or objects have fallen into the apparatus,
- C. If the apparatus has been exposed to rain or water,
- D. If the apparatus does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the apparatus to its normal operation,
- E. If the apparatus has been dropped or damaged in any way, and
- F. When the apparatus exhibits a distinct change in performance this indicates a need for service.

14. Object and Liquid Entry

Never push objects of any kind into the apparatus through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases shall be placed on the apparatus. Don't put candles or other burning objects on top of this unit.

15. Batteries

Always consider the environmental issues and follow local regulations when disposing of batteries.



16. The power supply and power cord for this apparatus is intended for indoor use only.

.....

§ 15.21 Information to user.

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. In cases where the manual is provided only in a form other than paper, such as on a computer disk or over the Internet, the information required by this section may be included in the manual in that alternative form, provided the user can reasonably be expected to have the capability to access information in that form.

OVERVIEW



REAR

1. Power

Connect to external power supply, included i the package.

2. Output to CVX external master volume control

Connect to CVX external master volume control (sold separately).

3. Channel selector

Choose between channel 1, 2 or 3. Set whole system to same channel (same as CTX transmitter and wireless speakers.)

4. ID code

On each Channel(1-2-3), there is 10 different ID codes.
Set whole system to same ID code.

TOP

5. Zone button

- Toggle between volume zone A, B, C, D, E, F and back to Master Volume.
- Set zone volume with volume knob. 8 second time out after last setting.
- The Zone volume can be adjusted -9 to +9. Default 0.
- Do not adjust any zone volume when Master volume is set to "00".

6. LED wireless indicator

Blue for wireless connection, Red for no connection (and Standby).

7. Volume control

- Use to control all zones at the same time, Master volume. Adjustable 0–31.
- Use to set individual zone level. (Press Zone button to toggle to desired zone.)
- Do not adjust any zone volume when Master volume is set to "00".